


DETAIL A



ASSEMBLY INSTRUCTIONS:

- A) Place spring nuts (item 5) in C channel at desired location for the cable manager.
- B) Align mounting slots in cable manager (item 1) with spring nuts. Secure using 3/8 flat and lock washers and 3/8-16 x 7/8 screw (items 2, 3 & 4).
- C) Ensure cable manager is perpendicular to bottom and tighten all screws.

PARTS LIST

ITEM No.	DESCRIPTION	QTY
1	VCT CABLE MANAGER	1
2	3/8 FLAT WASHER	3
3	3/8 LOCK WASHER	3
4	3/8-16 X 7/8 CAP HEX	3
5	3/8 SPRING NUT	3

TOOL BOX



9/16" Socket
Wrench



Square

