


CY3687 MoBL-USB™ FX2LP18 QUICK START GUIDE

CY3687 MoBL-USB™ FX2LP18 Quick Start Guide




1 Insert the installation CD/DVD into your CD/DVD drive and run cyautorun.exe on the CD/DVD root directory. First time users can accept the default option at each stage of the setup.



2 Set the switch SW2 in 'SAFE' mode as shown above.




3 Connect a USB A-to-B cable between the development board J2 connector and USB Host port on a Windows PC. Windows Hardware wizard window pops up at this moment. Follow the steps (5-10) outlined in section 6.2.1 of Kit User Guide. Point the Windows Hardware Wizard to the directory of the relevant USB driver for Windows OS platform to which the MOBL-USB FX2LP18 development board is connected.




4 Open Device Manager by right clicking on **My Computer > Manage > Device Manager**.

Note: In Windows vista/7, right-click on **Computer > Manage > Device Manager**.

The CY3687 MoBL-USB FX2LP18 DVK enumerates as 'Cypress MoBL-USB FX2LP18 Connect Model(3.4.5.000)' with VID=04B4 and PID=8614 in Device Manager as shown above.




5 Run Cyconsole from the following location:
Start > All Programs > Cypress > Cypress Suite USB 3.4.7 > CyConsole



6 Confirm successful Installation of drivers. Click on the "Get Dev" button to retrieve the device descriptor from your development board.

CY3687 MoBL-USB™ FX2LP18 QUICK START GUIDE

CY3687 MoBL-USB FX2LP18 Development Board Details



For the latest information about this kit visit
<http://www.cypress.com/go/CY3687>

