





Schurter




0041.9105.52000

Part Number:	0041.9105.52000
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSHBUTTON SPST-NO
Datasheets:	 0041.9105.52000.pdf
RoHs Status	 Lead free / RoHS Compliant
Stock Condition	16185 pcs stock
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION













Specifications of 0041.9105.52000

PART NUMBER	0041.9105.52000
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPST-NO
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	16185 pcs
DATA SHEET	 0041.9105.52000.pdf
TYPE	-
TERMINATION STYLE	-
SWITCH FUNCTION	-
SERIES	-
PANEL CUTOUT DIMENSIONS	-
PACKAGING	-
OPERATING TEMPERATURE	-
MOUNTING TYPE	-
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	-
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch
CURRENT RATING	-
COLOR - ACTUATOR/CAP	-
CIRCUIT	-
ACTUATOR TYPE	-

Related Tags

Schurter 0041.9105.52000	0041.9105.52000 Distributor	0041.9105.52000 Supplier
0041.9105.52000 Price	0041.9105.52000 Pictures	0041.9105.52000 Image
0041.9105.52000 PDF Datasheet	0041.9105.52000 Download Datasheet	0041.9105.52000 Datasheet
0041.9105.52000 Stock	Buy 0041.9105.52000	Buy Schurter 0041.9105.52000
Schurter 0041.9105.52000	Schurter Supplier	Schurter Distributor
Schurter 0041.9105.52000	Schurter Inc. 0041.9105.52000	

Related Products

<div></div> <div>0041.9141.7107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 26369 pcs <div>RFQ</div></div>	<div></div> <div>0041.9143.3307 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 23019 pcs <div>RFQ</div></div>
<div></div> <div>0041.9101.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 20670 pcs <div>RFQ</div></div>	<div></div> <div>0041.8856.1137 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 13670 pcs <div>RFQ</div></div>
<div></div> <div>0041.9141.1307 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 27287 pcs <div>RFQ</div></div>	<div></div> <div>0041.9101.81000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 24353 pcs <div>RFQ</div></div>
<div></div> <div>0041.9105.71000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16377 pcs <div>RFQ</div></div>	<div></div> <div>0041.8855.1107 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16786 pcs <div>RFQ</div></div>
<div></div> <div>0041.9102.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON DPST-NO In stock: 17566 pcs <div>RFQ</div></div>	<div></div> <div>0041.8860.1137 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 6270 pcs <div>RFQ</div></div>
<div></div> <div>0041.9141.3107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16016 pcs <div>RFQ</div></div>	<div></div> <div>0041.9105.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 17892 pcs <div>RFQ</div></div>