

S.SCHURTER

**Schurter** 

0041.8841.3107

Part Number:

Manufacturer/Brand:

Product description

RoHs Status Stock Condition

Datasheets:

Ship From Shipment Way 0041.8841.3107

Schurter

SWITCH PUSH SPST-NO 200MA 60V

0041.8841.3107.pdf

Lead free / RoHS Compliant 11574 pcs stock

Hong Kong

DHL/Fedex/TNT/UPS/EMS

**REQUEST FOR QUOTATION** 

Image may be representation. See specifications for product details.

**9.SCHURTE** 

ELECTRONIC COMPONE

	Specifications of 0041.8841.3107
	Specifications of 0041.0041.5107
PART NUMBER	0041.8841.3107
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSH SPST-NO 200MA 60V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	11574 pcs
DATA SHEET	0041.8841.3107.pdf
VOLTAGE RATING - DC	50V
VOLTAGE RATING - AC	60V
TYPE	Standard
TERMINATION STYLE	Solder Lug
SWITCH FUNCTION	Off-Mom
SERIES	LDT
PANEL CUTOUT DIMENSIONS	Circular - 8.00mm Dia
PACKAGING	Bulk
OTHER NAMES	0041.8841.3107-ND 486-3487
OPERATING TEMPERATURE	-25°C ~ 85°C
MOUNTING TYPE	Panel Mount, Front
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	10,000 Cycles
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP40
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	10,000 Cycles
DETAILED DESCRIPTION	Pushbutton Switch SPST-NO Standard Panel Mount, Front
CURRENT RATING	200mA (AC/DC)
COLOR - ACTUATOR/CAP	Red
CIRCUIT	SPST-NO
ACTUATOR TYPE	Round, Button

## **Related Tags**

Schurter 0041.8841.3107	0041.8841.3107 Distributor	0041.8841.3107 Supplier
0041.8841.3107 Price	0041.8841.3107 Pictures	0041.8841.3107 Image
0041.8841.3107 PDF Datasheet	0041.8841.3107 Download Datasheet	0041.8841.3107 Datasheet
0041.8841.3107 Stock	Buy 0041.8841.3107	Buy Schurter 0041.8841.3107
Schurter 0041.8841.3107	Schurter Supplier	Schurter Distributor
Schurter 0041.8841.3107	Schurter Inc. 0041.8841.3107	

## **Related Products**

0041.237	<b>'3</b>
M =	

Manufacturers: Schurter Description: SWITCH PUSHBUTTON 3PST 5A 250V

In stock: 6976 pcs

**RFQ** 

0041.8845.3107 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO

In stock: 19126 pcs **RFQ** 

0041.2374

0041.2372

0041.8841.6107 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V

In stock: 20223 pcs

**RFQ** 

SCHURTER

SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON 4PST 5A 250V

In stock: 4499 pcs

**RFQ** 



9.SCHURTER

9.SCHURTER

9.SCHURTER

SCHURTER

S.SCHURTER

0041.3101 Manufacturers: Schurter

Description: CONTACT BLOCK SPDT 6.3A 250V In stock: 5576 pcs

**RFQ** 

SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON DPST 5A 250V

In stock: 4656 pcs

**RFQ** 

0041.8843.7107 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO

In stock: 23606 pcs

**RFQ** 

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO

In stock: 17303 pcs

**RFQ** 

0041.3102 Manufacturers: Schurter

Description: CONTACT BLOCK SPDT 6.3A 250V

In stock: 2979 pcs

**RFQ** 

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V

0041.8841.3307

In stock: 6492 pcs

**RFQ** 

Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V

0041.8841.7107

In stock: 10970 pcs

**RFQ** 



Manufacturers: Schurter

0041.3009

Description: CONFIG SW BODY E-STOP NON-ILLUM In stock: 2367 pcs

**RFQ** 













