S.SCHURTER



9.SCHURTE

ELECTRONIC COMPONE

0041.8855.1107 **Schurter**

Part Number:

Manufacturer/Brand:

Product description

RoHs Status Stock Condition

Datasheets:

Ship From Shipment Way 0041.8855.1107

Schurter

SWITCH PUSHBUTTON SPST-NO

0041.8855.1107.pdf Lead free / RoHS Compliant

16786 pcs stock

Hong Kong DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.

	Specifications of 0041.8855.1107
PART NUMBER	0041.8855.1107
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPST-NO
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	16786 pcs
DATA SHEET	0041.8855.1107.pdf
TYPE	-
TERMINATION STYLE	-
SWITCH FUNCTION	-
SERIES	-
PANEL CUTOUT DIMENSIONS	-
PACKAGING	-
OPERATING TEMPERATURE	-
MOUNTING TYPE	-
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	-
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch
CURRENT RATING	-
COLOR - ACTUATOR/CAP	-
CIRCUIT	-
ACTUATOR TYPE	-

Related Tags

ŗ		
Schurter 0041.8855.1107	0041.8855.1107 Distributor	0041.8855.1107 Supplier
0041.8855.1107 Price	0041.8855.1107 Pictures	0041.8855.1107 Image
0041.8855.1107 PDF Datasheet	0041.8855.1107 Download Datasheet	0041.8855.1107 Datasheet
0041.8855.1107 Stock	Buy 0041.8855.1107	Buy Schurter 0041.8855.1107
Schurter 0041.8855.1107	Schurter Supplier	Schurter Distributor
Schurter 0041.8855.1107	Schurter Inc. 0041.8855.1107	

Related Products

S.SCHURTER
ELECTRONIC COMPONENTS

Manufacturers: Schurter Description: SWITCH PUSHBUTTON DPST-NO

0041.9102.72000

In stock: 17566 pcs

RFQ

SCHURTER

0041.9101.81000 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 24353 pcs

RFQ

0041.8860.1137

0041.8850.5127 Manufacturers: Schurter SCHURTER

Description: SWITCH PUSHBUTTON SPST-NO In stock: 13742 pcs

RFQ

SCHURTER

SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO

In stock: 6270 pcs

RFQ

SCHURTER

9.SCHURTER

9.SCHURTER

9.SCHURTER

0041.8851.3107 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V

In stock: 4471 pcs

RFQ

0041.8851.1107

Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16229 pcs

RFQ

0041.9101.72000

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO

In stock: 20670 pcs

RFQ

9.SCHURTER

0041.8846.5127 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 15845 pcs

RFQ

0041.8847.5127 Manufacturers: Schurter

Description: SWITCH PUSH DPST-NO 200MA 60V

In stock: 5944 pcs

RFQ

SCHURTER

0041.9105.52000 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 16185 pcs

RFQ

0041.8856.1137 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 13670 pcs

RFQ

SCHURTER

0041.8847.1137

Manufacturers: Schurter Description: SWITCH PUSH DPST-NO 200MA 60V

In stock: 11474 pcs **RFQ**



Copyright © 2020 Reliable Distributor of Electronic Components











