





Schurter




0041.9105.71000

Part Number:	0041.9105.71000
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSHBUTTON SPST-NO
Datasheets:	 0041.9105.71000.pdf
RoHs Status	 Lead free / RoHS Compliant
Stock Condition	16377 pcs stock
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION













Specifications of 0041.9105.71000

PART NUMBER	0041.9105.71000
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPST-NO
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	16377 pcs
DATA SHEET	 0041.9105.71000.pdf
TYPE	-
TERMINATION STYLE	-
SWITCH FUNCTION	-
SERIES	-
PANEL CUTOUT DIMENSIONS	-
PACKAGING	-
OPERATING TEMPERATURE	-
MOUNTING TYPE	-
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	-
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch
CURRENT RATING	-
COLOR - ACTUATOR/CAP	-
CIRCUIT	-
ACTUATOR TYPE	-

Related Tags

Schurter 0041.9105.71000	0041.9105.71000 Distributor	0041.9105.71000 Supplier
0041.9105.71000 Price	0041.9105.71000 Pictures	0041.9105.71000 Image
0041.9105.71000 PDF Datasheet	0041.9105.71000 Download Datasheet	0041.9105.71000 Datasheet
0041.9105.71000 Stock	Buy 0041.9105.71000	Buy Schurter 0041.9105.71000
Schurter 0041.9105.71000	Schurter Supplier	Schurter Distributor
Schurter 0041.9105.71000	Schurter Inc. 0041.9105.71000	

Related Products

<div></div> <div>0041.9141.3107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16016 pcs <div>RFQ</div></div>	<div></div> <div>0041.9105.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 17892 pcs <div>RFQ</div></div>
<div></div> <div>0041.9141.7107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 26369 pcs <div>RFQ</div></div>	<div></div> <div>0041.8856.1137 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 13670 pcs <div>RFQ</div></div>
<div></div> <div>0041.9102.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON DPST-NO In stock: 17566 pcs <div>RFQ</div></div>	<div></div> <div>0041.9143.3307 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 23019 pcs <div>RFQ</div></div>
<div></div> <div>0041.8860.1137 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 6270 pcs <div>RFQ</div></div>	<div></div> <div>0041.9105.52000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16185 pcs <div>RFQ</div></div>
<div></div> <div>0041.9141.1307 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 27287 pcs <div>RFQ</div></div>	<div></div> <div>0041.9146.1337 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 13069 pcs <div>RFQ</div></div>
<div></div> <div>0041.9101.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 20670 pcs <div>RFQ</div></div>	<div></div> <div>0041.9101.81000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 24353 pcs <div>RFQ</div></div>