S.SCHURTER



9.SCHURTE ELECTRONIC COMPONE

Schurter

1241.8449

Part Number:

Manufacturer/Brand:

Product description

RoHs Status Stock Condition

Datasheets:

Ship From Shipment Way 1241.8449

Schurter

SWITCH PUSHBUTTON SPDT 10A 250V

1241.8449.pdf

Lead free / RoHS Compliant 2177 pcs stock

Hong Kong DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.

	Specifications of 1241-9440
	Specifications of 1241.8449
PART NUMBER	1241.8449
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPDT 10A 250V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	2177 pcs
DATA SHEET	1241.8449.pdf
VOLTAGE RATING - AC	250V
TYPE	Vandal Resistant, Illuminated
TERMINATION STYLE	Quick Connect - 0.110" (2.8mm)
SWITCH FUNCTION	On-Mom
SERIES	MSM CS
PANEL CUTOUT DIMENSIONS	Circular - 19.10mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-25°C ~ 85°C
MOUNTING TYPE	Panel Mount, Front
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	1,500,000 Cycles
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP40
ILLUMINATION VOLTAGE (NOMINAL)	24 VDC
ILLUMINATION TYPE, COLOR	LED, Green
FEATURES	Ceramic Actuator
ELECTRICAL LIFE	50,000 Cycles
DETAILED DESCRIPTION	Pushbutton Switch SPDT Vandal Resistant, Illuminated Panel Mount, Front
CURRENT RATING	10A (AC)
COLOR - ACTUATOR/CAP	Clear (White Filter/Diffuser)
CIRCUIT	SPDT
ACTUATOR TYPE	Round, Button, Flush

Related Tags

Schurter 1241.8449	1241.8449 Distributor	1241.8449 Supplier
1241.8449 Price	1241.8449 Pictures	1241.8449 Image
1241.8449 PDF Datasheet	1241.8449 Download Datasheet	1241.8449 Datasheet
1241.8449 Stock	Buy 1241.8449	Buy Schurter 1241.8449
Schurter 1241.8449	Schurter Supplier	Schurter Distributor
Schurter 1241.8449	Schurter Inc. 1241.8449	

Related Products

1241.8485

9.SCHURTER

Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPDT 100MA 30V In stock: 1918 pcs

RFQ

9.SCHURTER

Manufacturers: Schurter

1241.8452

Description: SWITCH PUSHBUTTON SPDT 10A 250V In stock: 1775 pcs

RFQ

1241.8484

9.SCHURTER

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPDT 100MA 30V

In stock: 1714 pcs

RFQ

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPDT 10A 250V

In stock: 1814 pcs

RFQ

1241.8448

1241.8415

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPDT 100MA 30V

In stock: 1823 pcs

RFQ

9.SCHURTER

1241.8413 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPDT 100MA 30V In stock: 1804 pcs

RFQ

1241.8451 Manufacturers: Schurter

S.SCHURTER

Description: SWITCH PUSHBUTTON SPDT 10A 250V In stock: 1706 pcs

RFQ

S.SCHURTER

1241.8412 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPDT 100MA 30V In stock: 1745 pcs

RFQ

1241.8488

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPDT 100MA 30V In stock: 1864 pcs **RFQ**

1241.7236.1125000 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON DPST 12A 250V In stock: 1366 pcs

RFQ

Manufacturers: Schurter

1241.8416

Description: SWITCH PUSHBUTTON SPDT 100MA 30V In stock: 1872 pcs

RFQ

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPDT 100MA 30V

1241.8487

In stock: 1788 pcs

RFQ



9.SCHURTER













