



Schurter



0041.8845.3107

Part Number:	0041.8845.3107
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSHBUTTON SPST-NO
Datasheets:	 0041.8845.3107.pdf
RoHs Status	 Lead free / RoHS Compliant
Stock Condition	19126 pcs stock
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.

Specifications of 0041.8845.3107

PART NUMBER	0041.8845.3107
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPST-NO
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	19126 pcs
DATA SHEET	 0041.8845.3107.pdf
TYPE	-
TERMINATION STYLE	-
SWITCH FUNCTION	-
SERIES	-
PANEL CUTOUT DIMENSIONS	-
PACKAGING	-
OPERATING TEMPERATURE	-
MOUNTING TYPE	-
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	-
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch
CURRENT RATING	-
COLOR - ACTUATOR/CAP	-
CIRCUIT	-
ACTUATOR TYPE	-

Related Tags

Schurter 0041.8845.3107	0041.8845.3107 Distributor	0041.8845.3107 Supplier
0041.8845.3107 Price	0041.8845.3107 Pictures	0041.8845.3107 Image
0041.8845.3107 PDF Datasheet	0041.8845.3107 Download Datasheet	0041.8845.3107 Datasheet
0041.8845.3107 Stock	Buy 0041.8845.3107	Buy Schurter 0041.8845.3107
Schurter 0041.8845.3107	Schurter Supplier	Schurter Distributor
Schurter 0041.8845.3107	Schurter Inc. 0041.8845.3107	

Related Products

 0041.8847.5127 Manufacturers: Schurter Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 5944 pcs RFQ	 0041.8846.5127 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 15845 pcs RFQ
 0041.8841.3107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 11574 pcs RFQ	 0041.3102 Manufacturers: Schurter Description: CONTACT BLOCK SPDT 6.3A 250V In stock: 2979 pcs RFQ
 0041.8847.1137 Manufacturers: Schurter Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 11474 pcs RFQ	 0041.8845.4107 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 17303 pcs RFQ
 0041.8841.7107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 10970 pcs RFQ	 0041.8845.7107 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 20416 pcs RFQ
 0041.8843.7107 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 23606 pcs RFQ	 0041.8841.3307 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 6492 pcs RFQ
 0041.8841.6107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 20223 pcs RFQ	 0041.8846.3117 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 5352 pcs RFQ