





Schurter




0041.9141.1307

Part Number:	0041.9141.1307
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSH SPST-NO 200MA 60V
Datasheets:	 0041.9141.1307.pdf
RoHs Status	 Lead free / RoHS Compliant
Stock Condition	27287 pcs stock
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.













Specifications of 0041.9141.1307

PART NUMBER	0041.9141.1307
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSH SPST-NO 200MA 60V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	27287 pcs
DATA SHEET	 0041.9141.1307.pdf
VOLTAGE RATING - DC	50V
VOLTAGE RATING - AC	60V
TYPE	Standard
TERMINATION STYLE	PC Pin
SWITCH FUNCTION	Off-Mom
SERIES	LDT
PANEL CUTOUT DIMENSIONS	Circular - 8.00mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-25°C ~ 85°C
MOUNTING TYPE	Panel Mount, Front
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	10,000 Cycles
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP40
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	10,000 Cycles
DETAILED DESCRIPTION	Pushbutton Switch SPST-NO Standard Panel Mount, Front
CURRENT RATING	200mA (AC/DC)
COLOR - ACTUATOR/CAP	-
CIRCUIT	SPST-NO
ACTUATOR TYPE	Square, Button

Related Tags

Schurter 0041.9141.1307	0041.9141.1307 Distributor	0041.9141.1307 Supplier
0041.9141.1307 Price	0041.9141.1307 Pictures	0041.9141.1307 Image
0041.9141.1307 PDF Datasheet	0041.9141.1307 Download Datasheet	0041.9141.1307 Datasheet
0041.9141.1307 Stock	Buy 0041.9141.1307	Buy Schurter 0041.9141.1307
Schurter 0041.9141.1307	Schurter Supplier	Schurter Distributor
Schurter 0041.9141.1307	Schurter Inc. 0041.9141.1307	

Related Products

<div></div> <div>0041.9101.81000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 24353 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9105.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 17892 pcs</div> <div>RFQ</div>
<div></div> <div>0041.9146.3117 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 9762 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9143.3307 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 23019 pcs</div> <div>RFQ</div>
<div></div> <div>0041.9105.71000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16377 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9102.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON DPST-NO In stock: 17566 pcs</div> <div>RFQ</div>
<div></div> <div>0041.9146.1337 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 13069 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9101.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 20670 pcs</div> <div>RFQ</div>
<div></div> <div>0041.9146.3317 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16456 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9141.7107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 26369 pcs</div> <div>RFQ</div>
<div></div> <div>0041.9141.3107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16016 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9105.52000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16185 pcs</div> <div>RFQ</div>