





Schurter




Image may be representation. See specifications for product details.

0041.9156.5127

Part Number:	0041.9156.5127
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSH SPST-NO 200MA 60V
Datasheets:	 0041.9156.5127.pdf
RoHs Status	 Lead free / RoHS Compliant
Stock Condition	8605 pcs stock
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION













Specifications of 0041.9156.5127

PART NUMBER	0041.9156.5127
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSH SPST-NO 200MA 60V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	8605 pcs
DATA SHEET	 0041.9156.5127.pdf
VOLTAGE RATING - DC	50V
VOLTAGE RATING - AC	60V
TYPE	Standard, Illuminated
TERMINATION STYLE	PC Pin
SWITCH FUNCTION	Off-On
SERIES	LDS
PANEL CUTOUT DIMENSIONS	Circular - 8.00mm Dia
PACKAGING	Bulk
OTHER NAMES	0041.9156.5127-ND 486-3492
OPERATING TEMPERATURE	-25°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
MECHANICAL LIFE	10,000 Cycles
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP40
ILLUMINATION VOLTAGE (NOMINAL)	2 VDC
ILLUMINATION TYPE, COLOR	LED, Green
FEATURES	-
ELECTRICAL LIFE	10,000 Cycles
DETAILED DESCRIPTION	Pushbutton Switch SPST-NO Standard, Illuminated Panel Mount, Front
CURRENT RATING	200mA (AC/DC)
COLOR - ACTUATOR/CAP	Green
CIRCUIT	SPST-NO
ACTUATOR TYPE	Round, Button

Related Tags

Schurter 0041.9156.5127	0041.9156.5127 Distributor	0041.9156.5127 Supplier
0041.9156.5127 Price	0041.9156.5127 Pictures	0041.9156.5127 Image
0041.9156.5127 PDF Datasheet	0041.9156.5127 Download Datasheet	0041.9156.5127 Datasheet
0041.9156.5127 Stock	Buy 0041.9156.5127	Buy Schurter 0041.9156.5127
Schurter 0041.9156.5127	Schurter Supplier	Schurter Distributor
Schurter 0041.9156.5127	Schurter Inc. 0041.9156.5127	

Related Products

<div><div>0041.9160.3317 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 11686 pcs</div><div>RFQ</div></div>	<div><div>0041.9147.3317 Manufacturers: Schurter Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 8060 pcs</div><div>RFQ</div></div>
<div><div>0041.9151.7107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 26458 pcs</div><div>RFQ</div></div>	<div><div>0041.9160.1337 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 13542 pcs</div><div>RFQ</div></div>
<div><div>0041.9151.3107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 26487 pcs</div><div>RFQ</div></div>	<div><div>0041.9153.3107 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 22476 pcs</div><div>RFQ</div></div>
<div><div>0041.9150.5127 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 13245 pcs</div><div>RFQ</div></div>	<div><div>0041.9160.5127 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 11133 pcs</div><div>RFQ</div></div>
<div><div>0041.9157.1137 Manufacturers: Schurter Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 12803 pcs</div><div>RFQ</div></div>	<div><div>0041.9158.3117 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 14414 pcs</div><div>RFQ</div></div>
<div><div>0041.9157.5327 Manufacturers: Schurter Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 10073 pcs</div><div>RFQ</div></div>	<div><div>0041.9151.5307 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 25659 pcs</div><div>RFQ</div></div>