



Schurter

0041.9143.3307

Part Number:	0041.9143.3307
Manufacturer/Brand:	Schurter
Product description:	SWITCH PUSHBUTTON SPST-NO
Datasheets:	 0041.9143.3307.pdf
RoHS Status:	 Lead free / RoHS Compliant
Stock Condition:	23019 pcs stock
Ship From:	Hong Kong
Shipment Way:	DHL/Fedex/TNT/UPS/EMS

[REQUEST FOR QUOTATION](#)

Image may be representation. See specifications for product details.

Specifications of 0041.9143.3307

PART NUMBER	0041.9143.3307
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPST-NO
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	23019 pcs
DATA SHEET	 0041.9143.3307.pdf
TYPE	-
TERMINATION STYLE	-
SWITCH FUNCTION	-
SERIES	-
PANEL CUTOUT DIMENSIONS	-
PACKAGING	-
OPERATING TEMPERATURE	-
MOUNTING TYPE	-
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	-
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch
CURRENT RATING	-
COLOR - ACTUATOR/CAP	-
CIRCUIT	-
ACTUATOR TYPE	-

Related Tags

Schurter 0041.9143.3307	0041.9143.3307 Distributor	0041.9143.3307 Supplier
0041.9143.3307 Price	0041.9143.3307 Pictures	0041.9143.3307 Image
0041.9143.3307 PDF Datasheet	0041.9143.3307 Download Datasheet	0041.9143.3307 Datasheet
0041.9143.3307 Stock	Buy 0041.9143.3307	Buy Schurter 0041.9143.3307
Schurter 0041.9143.3307	Schurter Supplier	Schurter Distributor
Schurter 0041.9143.3307	Schurter Inc. 0041.9143.3307	

Related Products

 <p>0041.9105.52000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16185 pcs</p> <p>RFQ</p>	 <p>0041.9141.1307 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 27287 pcs</p> <p>RFQ</p>
 <p>0041.9141.7107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 26369 pcs</p> <p>RFQ</p>	 <p>0041.9146.3117 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 9762 pcs</p> <p>RFQ</p>
 <p>0041.9146.1337 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 13069 pcs</p> <p>RFQ</p>	 <p>0041.9147.3317 Manufacturers: Schurter Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 8060 pcs</p> <p>RFQ</p>
 <p>0041.9146.3317 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16456 pcs</p> <p>RFQ</p>	 <p>0041.9105.71000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16377 pcs</p> <p>RFQ</p>
 <p>0041.9105.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 17892 pcs</p> <p>RFQ</p>	 <p>0041.9141.3107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16016 pcs</p> <p>RFQ</p>
 <p>0041.9146.5327 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 15485 pcs</p> <p>RFQ</p>	 <p>0041.9146.5127 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 9919 pcs</p> <p>RFQ</p>