

S.SCHURTER

Schurter

0041.9151.3107

Part Number:

Manufacturer/Brand:

Product description Datasheets:

RoHs Status Stock Condition

Ship From Shipment Way 0041.9151.3107

Schurter

SWITCH PUSH SPST-NO 200MA 60V

0041.9151.3107.pdf

Lead free / RoHS Compliant

26487 pcs stock Hong Kong

DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.

9.SCHURTE

ELECTRONIC COMPONE

	Specifications of 0041.9151.3107
	Specifications of out 11/3101/01
PART NUMBER	0041.9151.3107
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSH SPST-NO 200MA 60V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	26487 pcs
DATA SHEET	0041.9151.3107.pdf
VOLTAGE RATING - DC	50V
VOLTAGE RATING - AC	60V
TYPE	Standard
TERMINATION STYLE	PC Pin
SWITCH FUNCTION	Off-On
SERIES	LDS
PANEL CUTOUT DIMENSIONS	Circular - 8.00mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-25°C ~ 85°C
MOUNTING TYPE	Panel Mount, Front
MECHANICAL LIFE	10,000 Cycles
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP40
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	10,000 Cycles
DETAILED DESCRIPTION	Pushbutton Switch SPST-NO Standard Panel Mount, Front
CURRENT RATING	200mA (AC/DC)
COLOR - ACTUATOR/CAP	Red
CIRCUIT	SPST-NO
ACTUATOR TYPE	Round, Button

Related Tags

Schurter 0041.9151.3107	0041.9151.3107 Distributor	0041.9151.3107 Supplier
0041.9151.3107 Price	0041.9151.3107 Pictures	0041.9151.3107 Image
0041.9151.3107 PDF Datasheet	0041.9151.3107 Download Datasheet	0041.9151.3107 Datasheet
0041.9151.3107 Stock	Buy 0041.9151.3107	Buy Schurter 0041.9151.3107
Schurter 0041.9151.3107	Schurter Supplier	Schurter Distributor
Schurter 0041.9151.3107	Schurter Inc. 0041.9151.3107	

Related Products

0041.9151.7107

Manufacturers: Schurter 9.SCHURTER

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 26458 pcs

RFQ

9.SCHURTER

Manufacturers: Schurter

0041.9146.3117

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 9762 pcs

RFQ

0041.9146.5327

Manufacturers: Schurter 9.SCHURTER

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 15485 pcs

RFQ

0041.9147.3317 Manufacturers: Schurter

Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 8060 pcs

RFQ

0041.9151.5307 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V

In stock: 25659 pcs

RFQ

9.SCHURTER

Manufacturers: Schurter

0041.9146.3317

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16456 pcs

RFQ

9.SCHURTER

0041.9146.5127 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 9919 pcs

RFQ

0041.9156.5127 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 8605 pcs

RFQ

Manufacturers: Schurter 9.SCHURTER

Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 12803 pcs

0041.9157.1137

RFQ

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO

0041.9150.5127

In stock: 13245 pcs

RFQ

Manufacturers: Schurter

0041.9157.5327

Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 10073 pcs

RFQ

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO

0041.9153.3107

In stock: 22476 pcs **RFQ**



9.SCHURTER













