





Schurter




0041.8860.1137

Part Number:	0041.8860.1137
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSHBUTTON SPST-NO
Datasheets:	 0041.8860.1137.pdf
RoHs Status	 Lead free / RoHS Compliant
Stock Condition	6270 pcs stock
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.













Specifications of 0041.8860.1137

PART NUMBER	0041.8860.1137
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPST-NO
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	6270 pcs
DATA SHEET	 0041.8860.1137.pdf
TYPE	-
TERMINATION STYLE	-
SWITCH FUNCTION	-
SERIES	-
PANEL CUTOUT DIMENSIONS	-
PACKAGING	-
OTHER NAMES	0041.8860.1137-ND 486-4276
OPERATING TEMPERATURE	-
MOUNTING TYPE	-
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	-
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch
CURRENT RATING	-
COLOR - ACTUATOR/CAP	-
CIRCUIT	-
ACTUATOR TYPE	-

Related Tags

Schurter 0041.8860.1137	0041.8860.1137 Distributor	0041.8860.1137 Supplier
0041.8860.1137 Price	0041.8860.1137 Pictures	0041.8860.1137 Image
0041.8860.1137 PDF Datasheet	0041.8860.1137 Download Datasheet	0041.8860.1137 Datasheet
0041.8860.1137 Stock	Buy 0041.8860.1137	Buy Schurter 0041.8860.1137
Schurter 0041.8860.1137	Schurter Supplier	Schurter Distributor
Schurter 0041.8860.1137	Schurter Inc. 0041.8860.1137	

Related Products

<div></div> <div>0041.9105.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 17892 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9105.71000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16377 pcs</div> <div>RFQ</div>
<div></div> <div>0041.8851.3107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 4471 pcs</div> <div>RFQ</div>	<div></div> <div>0041.8851.1107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16229 pcs</div> <div>RFQ</div>
<div></div> <div>0041.8847.5127 Manufacturers: Schurter Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 5944 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9102.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON DPST-NO In stock: 17566 pcs</div> <div>RFQ</div>
<div></div> <div>0041.9101.81000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 24353 pcs</div> <div>RFQ</div>	<div></div> <div>0041.8850.5127 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 13742 pcs</div> <div>RFQ</div>
<div></div> <div>0041.8856.1137 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 13670 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9101.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 20670 pcs</div> <div>RFQ</div>
<div></div> <div>0041.8855.1107 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16786 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9105.52000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16185 pcs</div> <div>RFQ</div>