

SCHURTER

Schurter

0041.8856.1137

Part Number:

Manufacturer/Brand:

Product description

RoHs Status Stock Condition

Datasheets:

Ship From Shipment Way 0041.8856.1137

Schurter

SWITCH PUSH SPST-NO 200MA 60V

Lead free / RoHS Compliant

0041.8856.1137.pdf

13670 pcs stock

Hong Kong

DHL/Fedex/TNT/UPS/EMS



5.SCHURTE

Image may be representation. See specifications for product details.

Specifications of 0041.8856.1137

REQUEST FOR QUOTATION

PART NUMBER 0041.8856.1137 **MANUFACTURER** Schurter **DESCRIPTION** SWITCH PUSH SPST-NO 200MA 60V LEAD FREE STATUS / ROHS STATUS Lead free / RoHS Compliant **QUANTITY AVAILABLE** 13670 pcs 0041.8856.1137.pdf DATA SHEET **VOLTAGE RATING - DC** 50V **VOLTAGE RATING - AC** 60V **TYPE** Standard, Illuminated **TERMINATION STYLE** Solder Lug **SWITCH FUNCTION** Off-On LDS **SERIES** Circular - 8.00mm Dia PANEL CUTOUT DIMENSIONS Bulk **PACKAGING OPERATING TEMPERATURE** -25°C ~ 60°C MOUNTING TYPE Panel Mount, Front 1 (Unlimited) MOISTURE SENSITIVITY LEVEL (MSL) 10,000 Cycles MECHANICAL LIFE Lead free / RoHS Compliant LEAD FREE STATUS / ROHS STATUS IP40 **INGRESS PROTECTION** ILLUMINATION VOLTAGE (NOMINAL) ILLUMINATION TYPE, COLOR **FEATURES** 10,000 Cycles ELECTRICAL LIFE **DETAILED DESCRIPTION** Pushbutton Switch SPST-NO Standard, Illuminated Panel Mount, Front 200mA (AC/DC) **CURRENT RATING** COLOR - ACTUATOR/CAP CIRCUIT SPST-NO

Related Tags

Round, Button

Schurter 0041.8856.1137	0041.8856.1137 Distributor	0041.8856.1137 Supplier
0041.8856.1137 Price	0041.8856.1137 Pictures	0041.8856.1137 Image
0041.8856.1137 PDF Datasheet	0041.8856.1137 Download Datasheet	0041.8856.1137 Datasheet
0041.8856.1137 Stock	Buy 0041.8856.1137	Buy Schurter 0041.8856.1137
Schurter 0041.8856.1137	Schurter Supplier	Schurter Distributor
Schurter 0041.8856.1137	Schurter Inc. 0041.8856.1137	

Related Products

0041.8850.5127

Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 13742 pcs

RFQ

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V

0041.8851.3107

In stock: 4471 pcs

RFQ

0041.8855.1107 Manufacturers: Schurter 9.SCHURTER

9.SCHURTER

9.SCHURTER

S.SCHURTER

9.SCHURTER

9.SCHURTER

ACTUATOR TYPE

Description: SWITCH PUSHBUTTON SPST-NO In stock: 16786 pcs

RFQ

9.SCHURTER

0041.8847.1137 Manufacturers: Schurter

Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 11474 pcs

RFQ

0041.8847.5127 Manufacturers: Schurter

Description: SWITCH PUSH DPST-NO 200MA 60V

In stock: 5944 pcs

RFQ

9.SCHURTER

0041.8860.1137 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 6270 pcs

RFQ

0041.9101.81000 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 24353 pcs

RFQ

S.SCHURTER

0041.9102.72000 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON DPST-NO In stock: 17566 pcs

RFQ

0041.8851.1107 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16229 pcs

RFQ

9.SCHURTER

0041.9101.72000

Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 20670 pcs

RFQ

Manufacturers: Schurter

0041.9105.52000

In stock: 16185 pcs **RFQ**

Description: SWITCH PUSHBUTTON SPST-NO 9.SCHURTER Manufacturers: Schurter

0041.9105.71000

Description: SWITCH PUSHBUTTON SPST-NO In stock: 16377 pcs

RFQ

Copyright © 2020 Reliable Distributor of Electronic Components E-mail: Info@infinity-electronic.com

Address: 17F, Gaylord Commercial Building, 114-118 Lockhart Road, Wan Chai, Hong Kong











