

SCHURTER

Schurter

0041.9151.5307

Part Number:

Manufacturer/Brand:

Product description

Datasheets:

RoHs Status Stock Condition

Ship From Shipment Way 0041.9151.5307

Schurter

SWITCH PUSH SPST-NO 200MA 60V

0041.9151.5307.pdf

Lead free / RoHS Compliant 25659 pcs stock

Hong Kong DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.

9.SCHURTE

ELECTRONIC COMPONE

Specifications of 0041.9151.5307

PART NUMBER 0041.9151.5307 **MANUFACTURER** Schurter **DESCRIPTION** SWITCH PUSH SPST-NO 200MA 60V LEAD FREE STATUS / ROHS STATUS Lead free / RoHS Compliant **QUANTITY AVAILABLE** 25659 pcs 0041.9151.5307.pdf DATA SHEET **VOLTAGE RATING - DC** 50V **VOLTAGE RATING - AC** 60V **TYPE** Standard **TERMINATION STYLE** PC Pin Off-On **SWITCH FUNCTION** LDS **SERIES** Circular - 8.00mm Dia PANEL CUTOUT DIMENSIONS **PACKAGING** Bulk **OPERATING TEMPERATURE** -25°C ~ 85°C MOUNTING TYPE Panel Mount, Front MOISTURE SENSITIVITY LEVEL (MSL) 1 (Unlimited) 10,000 Cycles MECHANICAL LIFE Lead free / RoHS Compliant LEAD FREE STATUS / ROHS STATUS **INGRESS PROTECTION** IP40 ILLUMINATION VOLTAGE (NOMINAL) ILLUMINATION TYPE, COLOR **FEATURES** 10,000 Cycles ELECTRICAL LIFE **DETAILED DESCRIPTION** Pushbutton Switch SPST-NO Standard Panel Mount, Front 200mA (AC/DC) **CURRENT RATING** COLOR - ACTUATOR/CAP Green SPST-NO CIRCUIT

Related Tags

Square, Button

| · | | |
|------------------------------|-----------------------------------|-----------------------------|
| Schurter 0041.9151.5307 | 0041.9151.5307 Distributor | 0041.9151.5307 Supplier |
| 0041.9151.5307 Price | 0041.9151.5307 Pictures | 0041.9151.5307 Image |
| 0041.9151.5307 PDF Datasheet | 0041.9151.5307 Download Datasheet | 0041.9151.5307 Datasheet |
| 0041.9151.5307 Stock | Buy 0041.9151.5307 | Buy Schurter 0041.9151.5307 |
| Schurter 0041.9151.5307 | Schurter Supplier | Schurter Distributor |
| Schurter 0041.9151.5307 | Schurter Inc. 0041.9151.5307 | |

Related Products

0041.9153.3107 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 22476 pcs

RFQ

9.SCHURTER

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V

0041.9146.5327

In stock: 15485 pcs

RFQ

Manufacturers: Schurter 9.SCHURTER

9.SCHURTER

9.SCHURTER

ACTUATOR TYPE

Description: SWITCH PUSH DPST-NO 200MA 60V

0041.9157.1137

In stock: 12803 pcs

RFQ

0041.9151.3107

Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 26487 pcs

RFQ

0041.9146.5127

Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 9919 pcs

RFQ

9.SCHURTER

0041.9151.7107 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 26458 pcs

RFQ

0041.9146.3317 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V

In stock: 16456 pcs

RFQ

0041.9147.3317 Manufacturers: Schurter

Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 8060 pcs

RFQ

Manufacturers: Schurter

0041.9156.5127

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 8605 pcs

RFQ

9.SCHURTER

0041.9158.3117 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO

In stock: 14414 pcs

RFQ

0041.9157.5327 Manufacturers: Schurter

Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 10073 pcs


RFQ

9.SCHURTER

0041.9150.5127 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 13245 pcs

RFQ





9.SCHURTER











