

**SCHURTER**
ELECTRONIC COMPONENTS

Schurter

**SCHURTE**
ELECTRONIC COMPONE

0041.9101.81000

Part Number:	0041.9101.81000
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSHBUTTON SPST-NO
Datasheets:	 0041.9101.81000.pdf
RoHs Status	 Lead free / RoHS Compliant
Stock Condition	24353 pcs stock
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.

Specifications of 0041.9101.81000

PART NUMBER	0041.9101.81000
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPST-NO
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	24353 pcs
DATA SHEET	 0041.9101.81000.pdf
TYPE	-
TERMINATION STYLE	-
SWITCH FUNCTION	-
SERIES	-
PANEL CUTOUT DIMENSIONS	-
PACKAGING	-
OPERATING TEMPERATURE	-
MOUNTING TYPE	-
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	-
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch
CURRENT RATING	-
COLOR - ACTUATOR/CAP	-
CIRCUIT	-
ACTUATOR TYPE	-

Related Tags

Schurter 0041.9101.81000	0041.9101.81000 Distributor	0041.9101.81000 Supplier
0041.9101.81000 Price	0041.9101.81000 Pictures	0041.9101.81000 Image
0041.9101.81000 PDF Datasheet	0041.9101.81000 Download Datasheet	0041.9101.81000 Datasheet
0041.9101.81000 Stock	Buy 0041.9101.81000	Buy Schurter 0041.9101.81000
Schurter 0041.9101.81000	Schurter Supplier	Schurter Distributor
Schurter 0041.9101.81000	Schurter Inc. 0041.9101.81000	

Related Products

SCHURTER ELECTRONIC COMPONENTS 0041.8851.3107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 4471 pcs RFQ	SCHURTER ELECTRONIC COMPONENTS 0041.9105.52000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16185 pcs RFQ
SCHURTER ELECTRONIC COMPONENTS 0041.9141.3107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16016 pcs RFQ	SCHURTER ELECTRONIC COMPONENTS 0041.9102.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON DPST-NO In stock: 17566 pcs RFQ
SCHURTER ELECTRONIC COMPONENTS 0041.9105.71000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16377 pcs RFQ	SCHURTER ELECTRONIC COMPONENTS 0041.9141.1307 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 27287 pcs RFQ
SCHURTER ELECTRONIC COMPONENTS 0041.9101.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 20670 pcs RFQ	SCHURTER ELECTRONIC COMPONENTS 0041.8860.1137 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 6270 pcs RFQ
SCHURTER ELECTRONIC COMPONENTS 0041.9105.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 17892 pcs RFQ	SCHURTER ELECTRONIC COMPONENTS 0041.8856.1137 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 13670 pcs RFQ
SCHURTER ELECTRONIC COMPONENTS 0041.8851.1107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16229 pcs RFQ	SCHURTER ELECTRONIC COMPONENTS 0041.8855.1107 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16786 pcs RFQ