



Schurter



1241.3271

Part Number:	1241.3271
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSHBUTTON
Datasheets:	
RoHs Status	 Lead free / RoHS Compliant
Stock Condition	3010 pcs stock
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION













Specifications of 1241.3271

PART NUMBER	1241.3271
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	3010 pcs
DATA SHEET	
TYPE	-
TERMINATION STYLE	-
SWITCH FUNCTION	-
SERIES	-
PANEL CUTOUT DIMENSIONS	-
PACKAGING	-
OPERATING TEMPERATURE	-
MOUNTING TYPE	-
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	-
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch
CURRENT RATING	-
COLOR - ACTUATOR/CAP	-
CIRCUIT	-
ACTUATOR TYPE	-

Related Tags

Schurter 1241.3271	1241.3271 Distributor	1241.3271 Supplier
1241.3271 Price	1241.3271 Pictures	1241.3271 Image
1241.3271 PDF Datasheet	1241.3271 Download Datasheet	1241.3271 Datasheet
1241.3271 Stock	Buy 1241.3271	Buy Schurter 1241.3271
Schurter 1241.3271	Schurter Supplier	Schurter Distributor
Schurter 1241.3271	Schurter Inc. 1241.3271	

Related Products

<div></div> <div>1241.3257 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 100MA 42V In stock: 1271 pcs RFQ</div>	<div></div> <div>1241.3523 Manufacturers: Schurter Description: SWITCH PUSHBUTTON In stock: 3120 pcs RFQ</div>
<div></div> <div>1241.3258 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 100MA 42V In stock: 1307 pcs RFQ</div>	<div></div> <div>1241.3256 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 100MA 42V In stock: 1247 pcs RFQ</div>
<div></div> <div>1241.3261 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 100MA 42V In stock: 1278 pcs RFQ</div>	<div></div> <div>1241.3312 Manufacturers: Schurter Description: SWITCH PUSHBUTTON In stock: 1650 pcs RFQ</div>
<div></div> <div>1241.3428 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 100MA 42V In stock: 1431 pcs RFQ</div>	<div></div> <div>1241.3259 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 100MA 42V In stock: 1335 pcs RFQ</div>
<div></div> <div>1241.3318 Manufacturers: Schurter Description: SWITCH PUSHBUTTON In stock: 1394 pcs RFQ</div>	<div></div> <div>1241.3350 Manufacturers: Schurter Description: SWITCH PUSHBUTTON In stock: 2837 pcs RFQ</div>
<div></div> <div>1241.3669 Manufacturers: Schurter Description: PSE22 NO 00 A10 RI RGB In stock: 1109 pcs RFQ</div>	<div></div> <div>1241.3260 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 100MA 42V In stock: 1091 pcs RFQ</div>