



Schurter

0041.9141.7107

Part Number:	0041.9141.7107
Manufacturer/Brand:	Schurter
Product description:	SWITCH PUSH SPST-NO 200MA 60V
Datasheets:	 0041.9141.7107.pdf
RoHS Status:	 Lead free / RoHS Compliant
Stock Condition:	26369 pcs stock
Ship From:	Hong Kong
Shipment Way:	DHL/Fedex/TNT/UPS/EMS

[REQUEST FOR QUOTATION](#)

Image may be representation. See specifications for product details.

Specifications of 0041.9141.7107

PART NUMBER	0041.9141.7107
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSH SPST-NO 200MA 60V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	26369 pcs
DATA SHEET	 0041.9141.7107.pdf
VOLTAGE RATING - DC	50V
VOLTAGE RATING - AC	60V
TYPE	Standard
TERMINATION STYLE	PC Pin
SWITCH FUNCTION	Off-Mom
SERIES	LDT
PANEL CUTOUT DIMENSIONS	Circular - 8.00mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-25°C ~ 85°C
MOUNTING TYPE	Panel Mount, Front
MECHANICAL LIFE	10,000 Cycles
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP40
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	10,000 Cycles
DETAILED DESCRIPTION	Pushbutton Switch SPST-NO Standard Panel Mount, Front
CURRENT RATING	200mA (AC/DC)
COLOR - ACTUATOR/CAP	Black
CIRCUIT	SPST-NO
ACTUATOR TYPE	Round, Button

Related Tags

Schurter 0041.9141.7107	0041.9141.7107 Distributor	0041.9141.7107 Supplier
0041.9141.7107 Price	0041.9141.7107 Pictures	0041.9141.7107 Image
0041.9141.7107 PDF Datasheet	0041.9141.7107 Download Datasheet	0041.9141.7107 Datasheet
0041.9141.7107 Stock	Buy 0041.9141.7107	Buy Schurter 0041.9141.7107
Schurter 0041.9141.7107	Schurter Supplier	Schurter Distributor
Schurter 0041.9141.7107	Schurter Inc. 0041.9141.7107	

Related Products

 <p>0041.9146.5127 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 9919 pcs</p> <p>RFQ</p>	 <p>0041.9141.1307 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 27287 pcs</p> <p>RFQ</p>
 <p>0041.9105.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 17892 pcs</p> <p>RFQ</p>	 <p>0041.9105.71000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16377 pcs</p> <p>RFQ</p>
 <p>0041.9143.3307 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 23019 pcs</p> <p>RFQ</p>	 <p>0041.9105.52000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16185 pcs</p> <p>RFQ</p>
 <p>0041.9141.3107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16016 pcs</p> <p>RFQ</p>	 <p>0041.9146.5327 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 15485 pcs</p> <p>RFQ</p>
 <p>0041.9146.1337 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 13069 pcs</p> <p>RFQ</p>	 <p>0041.9102.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON DPST-NO In stock: 17566 pcs</p> <p>RFQ</p>
 <p>0041.9146.3117 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 9762 pcs</p> <p>RFQ</p>	 <p>0041.9146.3317 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16456 pcs</p> <p>RFQ</p>