



**SCHURTER**
ELECTRONIC COMPONENTS

Schurter


**SCHURTE**
ELECTRONIC COMPONE

0041.9141.3107

Part Number:	0041.9141.3107
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSH SPST-NO 200MA 60V
Datasheets:	 0041.9141.3107.pdf
RoHs Status	 Lead free / RoHS Compliant
Stock Condition	16016 pcs stock
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION













Specifications of 0041.9141.3107

PART NUMBER	0041.9141.3107
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSH SPST-NO 200MA 60V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	16016 pcs
DATA SHEET	 0041.9141.3107.pdf
VOLTAGE RATING - DC	50V
VOLTAGE RATING - AC	60V
TYPE	Standard
TERMINATION STYLE	PC Pin
SWITCH FUNCTION	Off-Mom
SERIES	LDT
PANEL CUTOUT DIMENSIONS	Circular - 8.00mm Dia
PACKAGING	Bulk
OTHER NAMES	0041.9141.3107-ND 486-3489
OPERATING TEMPERATURE	-25°C ~ 85°C
MOUNTING TYPE	Panel Mount, Front
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	10,000 Cycles
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP40
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	10,000 Cycles
DETAILED DESCRIPTION	Pushbutton Switch SPST-NO Standard Panel Mount, Front
CURRENT RATING	200mA (AC/DC)
COLOR - ACTUATOR/CAP	Red
CIRCUIT	SPST-NO
ACTUATOR TYPE	Round, Button

Related Tags

Schurter 0041.9141.3107	0041.9141.3107 Distributor	0041.9141.3107 Supplier
0041.9141.3107 Price	0041.9141.3107 Pictures	0041.9141.3107 Image
0041.9141.3107 PDF Datasheet	0041.9141.3107 Download Datasheet	0041.9141.3107 Datasheet
0041.9141.3107 Stock	Buy 0041.9141.3107	Buy Schurter 0041.9141.3107
Schurter 0041.9141.3107	Schurter Supplier	Schurter Distributor
Schurter 0041.9141.3107	Schurter Inc. 0041.9141.3107	

Related Products

<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.9141.1307 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 27287 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.9143.3307 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 23019 pcs</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.9146.5127 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 9919 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.9102.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON DPST-NO In stock: 17566 pcs</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.9105.72000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 17892 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.9101.81000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 24353 pcs</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.9146.3317 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16456 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.9146.1337 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 13069 pcs</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.9141.7107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 26369 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.9146.3117 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 9762 pcs</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.9105.52000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16185 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.9105.71000 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16377 pcs</div> <div>RFQ</div>