S.SCHURTER



**9.SCHURTE** ELECTRONIC COMPONE

**Schurter** 

1241.8487

Part Number:

Manufacturer/Brand:

Product description

RoHs Status Stock Condition Ship From

Datasheets:

Shipment Way

1241.8487

Schurter

SWITCH PUSHBUTTON SPDT 100MA 30V

1241.8487.pdf

Lead free / RoHS Compliant 1788 pcs stock

Hong Kong DHL/Fedex/TNT/UPS/EMS

**REQUEST FOR QUOTATION** 

Image may be representation. See specifications for product details.

	Specifications of 1241.8487	
PART NUMBER	1241.8487	
MANUFACTURER	Schurter	
DESCRIPTION	SWITCH PUSHBUTTON SPDT 100MA 30V	
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant	
QUANTITY AVAILABLE	1788 pcs	
DATA SHEET	1241.8487.pdf	
VOLTAGE RATING - DC	30V	
TYPE	Vandal Resistant, Illuminated	
TERMINATION STYLE	Quick Connect - 0.110" (2.8mm)	
SWITCH FUNCTION	On-Mom	
SERIES	MSM CS	
PANEL CUTOUT DIMENSIONS	Circular - 22.10mm Dia	
PACKAGING	Bulk	
OPERATING TEMPERATURE	-25°C ~ 85°C	
MOUNTING TYPE	Panel Mount, Front	
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)	
MECHANICAL LIFE	1,500,000 Cycles	
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant	
INGRESS PROTECTION	IP40	
ILLUMINATION VOLTAGE (NOMINAL)	24 VDC	
ILLUMINATION TYPE, COLOR	LED, Blue	
FEATURES	Ceramic Actuator	
ELECTRICAL LIFE	200,000 Cycles	
DETAILED DESCRIPTION	Pushbutton Switch SPDT Vandal Resistant, Illuminated Panel Mount, Front	
CURRENT RATING	100mA (DC)	
COLOR - ACTUATOR/CAP	Clear (White Filter/Diffuser)	
CIRCUIT	SPDT	
ACTUATOR TYPE	Round, Button, Flush	

## **Related Tags**

Schurter 1241.8487	1241.8487 Distributor	1241.8487 Supplier
1241.8487 Price	1241.8487 Pictures	1241.8487 Image
1241.8487 PDF Datasheet	1241.8487 Download Datasheet	1241.8487 Datasheet
1241.8487 Stock	Buy 1241.8487	Buy Schurter 1241.8487
Schurter 1241.8487	Schurter Supplier	Schurter Distributor
Schurter 1241.8487	Schurter Inc. 1241.8487	

## **Related Products**

1241.8448

9.SCHURTER

Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPDT 10A 250V In stock: 1814 pcs

**RFQ** 

1241.8524

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPDT 10A 250V

1241.8452

In stock: 1775 pcs

**RFQ** 

9.SCHURTER

9.SCHURTER

S.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPDT 10A 250V

In stock: 1768 pcs

**RFQ** 

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST 12A 250V

In stock: 1578 pcs

**RFQ** 

1241.8451

1241.8544

1241.8484

Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPDT 100MA 30V In stock: 1714 pcs

**RFQ** 

9.SCHURTER

Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPDT 10A 250V In stock: 1706 pcs

**RFQ** 

1241.8485 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPDT 100MA 30V

In stock: 1918 pcs

**RFQ** 

S.SCHURTER

1241.8449 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPDT 10A 250V In stock: 2177 pcs

**RFQ** 

1241.8520 Manufacturers: Schurter 9.SCHURTER

Description: SWITCH PUSHBUTTON SPDT 10A 250V

In stock: 2108 pcs **RFQ** 

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPDT 10A 250V

1241.8521

In stock: 2080 pcs

**RFQ** 

Manufacturers: Schurter

1241.8523

Description: SWITCH PUSHBUTTON SPDT 10A 250V In stock: 2145 pcs

**RFQ** 


9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPDT 100MA 30V

1241.8488

In stock: 1864 pcs

**RFQ** 



9.SCHURTER

