





Schurter




0041.9151.7107

Part Number:	0041.9151.7107
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSH SPST-NO 200MA 60V
Datasheets:	 0041.9151.7107.pdf
RoHs Status	 Lead free / RoHS Compliant
Stock Condition	26458 pcs stock
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION













Specifications of 0041.9151.7107

PART NUMBER	0041.9151.7107
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSH SPST-NO 200MA 60V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	26458 pcs
DATA SHEET	 0041.9151.7107.pdf
VOLTAGE RATING - DC	50V
VOLTAGE RATING - AC	60V
TYPE	Standard
TERMINATION STYLE	PC Pin
SWITCH FUNCTION	Off-On
SERIES	LDS
PANEL CUTOUT DIMENSIONS	Circular - 8.00mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-25°C ~ 85°C
MOUNTING TYPE	Panel Mount, Front
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	10,000 Cycles
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP40
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	10,000 Cycles
DETAILED DESCRIPTION	Pushbutton Switch SPST-NO Standard Panel Mount, Front
CURRENT RATING	200mA (AC/DC)
COLOR - ACTUATOR/CAP	Black
CIRCUIT	SPST-NO
ACTUATOR TYPE	Round, Button

Related Tags

Schurter 0041.9151.7107	0041.9151.7107 Distributor	0041.9151.7107 Supplier
0041.9151.7107 Price	0041.9151.7107 Pictures	0041.9151.7107 Image
0041.9151.7107 PDF Datasheet	0041.9151.7107 Download Datasheet	0041.9151.7107 Datasheet
0041.9151.7107 Stock	Buy 0041.9151.7107	Buy Schurter 0041.9151.7107
Schurter 0041.9151.7107	Schurter Supplier	Schurter Distributor
Schurter 0041.9151.7107	Schurter Inc. 0041.9151.7107	

Related Products

<div></div> <div>0041.9151.5307</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSH SPST-NO 200MA 60V</div> <div>In stock: 25659 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9156.5127</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSH SPST-NO 200MA 60V</div> <div>In stock: 8605 pcs</div> <div>RFQ</div>
<div></div> <div>0041.9151.3107</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSH SPST-NO 200MA 60V</div> <div>In stock: 26487 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9150.5127</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST-NO</div> <div>In stock: 13245 pcs</div> <div>RFQ</div>
<div></div> <div>0041.9146.5327</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSH SPST-NO 200MA 60V</div> <div>In stock: 15485 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9158.3117</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST-NO</div> <div>In stock: 14414 pcs</div> <div>RFQ</div>
<div></div> <div>0041.9147.3317</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSH DPST-NO 200MA 60V</div> <div>In stock: 8060 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9157.5327</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSH DPST-NO 200MA 60V</div> <div>In stock: 10073 pcs</div> <div>RFQ</div>
<div></div> <div>0041.9157.1137</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSH DPST-NO 200MA 60V</div> <div>In stock: 12803 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9153.3107</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST-NO</div> <div>In stock: 22476 pcs</div> <div>RFQ</div>
<div></div> <div>0041.9146.5127</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSH SPST-NO 200MA 60V</div> <div>In stock: 9919 pcs</div> <div>RFQ</div>	<div></div> <div>0041.9160.1337</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST-NO</div> <div>In stock: 13542 pcs</div> <div>RFQ</div>