

S.SCHURTER

**Schurter** 

0041.8850.5127

Part Number:

Manufacturer/Brand:

Product description

RoHs Status Stock Condition

Datasheets:

Ship From Shipment Way 0041.8850.5127

Schurter

SWITCH PUSHBUTTON SPST-NO

0041.8850.5127.pdf

Lead free / RoHS Compliant 13742 pcs stock

Hong Kong

DHL/Fedex/TNT/UPS/EMS



**REQUEST FOR QUOTATION** 

Image may be representation. See specifications for product details.

	Specifications of 0041.8850.5127
	Specifications of 00+1:0030.3127
PART NUMBER	0041.8850.5127
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPST-NO
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	13742 pcs
DATA SHEET	0041.8850.5127.pdf
TYPE	-
TERMINATION STYLE	-
SWITCH FUNCTION	-
SERIES	-
PANEL CUTOUT DIMENSIONS	-
PACKAGING	-
OPERATING TEMPERATURE	-
MOUNTING TYPE	-
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	-
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch
CURRENT RATING	-
COLOR - ACTUATOR/CAP	-
CIRCUIT	-
ACTUATOR TYPE	-

## **Related Tags**

·		
Schurter 0041.8850.5127	0041.8850.5127 Distributor	0041.8850.5127 Supplier
0041.8850.5127 Price	0041.8850.5127 Pictures	0041.8850.5127 Image
0041.8850.5127 PDF Datasheet	0041.8850.5127 Download Datasheet	0041.8850.5127 Datasheet
0041.8850.5127 Stock	Buy 0041.8850.5127	Buy Schurter 0041.8850.5127
Schurter 0041.8850.5127	Schurter Supplier	Schurter Distributor
Schurter 0041.8850.5127	Schurter Inc. 0041.8850.5127	

## **Related Products**

SCHURTER

Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V

0041.8846.3117

In stock: 5352 pcs

**RFQ** 

SCHURTER

Manufacturers: Schurter

0041.8851.1107

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16229 pcs

**RFQ** 

0041.8847.1137

0041.8847.5127 SCHURTER

Manufacturers: Schurter

Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 5944 pcs

**RFQ** 

SCHURTER

Manufacturers: Schurter Description: SWITCH PUSH DPST-NO 200MA 60V

In stock: 11474 pcs **RFQ** 

0041.8845.7107 Manufacturers: Schurter

SCHURTER

Description: SWITCH PUSHBUTTON SPST-NO In stock: 20416 pcs

**RFQ** 

SCHURTER

0041.8860.1137 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 6270 pcs

**RFQ** 

0041.8845.4107

0041.8856.1137 Manufacturers: Schurter

9.SCHURTER Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 13670 pcs

**RFQ** 

9.SCHURTER

Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 17303 pcs

**RFQ** 

0041.8846.5127 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V

In stock: 15845 pcs

**RFQ** 

SCHURTER

0041.9101.72000 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 20670 pcs

**RFQ** 

0041.8851.3107 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 4471 pcs

**RFQ** 

SCHURTER

0041.8855.1107

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO

In stock: 16786 pcs **RFQ** 



**Copyright © 2020 Reliable Distributor of Electronic Components** 

9.SCHURTER

9.SCHURTER











