



SCHURTER
ELECTRONIC COMPONENTS

Schurter




CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S

Part Number:	CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSHBUTTON SPST 100MA 42V
Datasheets:	 CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S.pdf
RoHs Status	 Lead free / RoHS Compliant
Stock Condition	4957 pcs stock
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION

Image may be representation. See specifications for product details.


Specifications of CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S

PART NUMBER	CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPST 100MA 42V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	4957 pcs
DATA SHEET	 CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S.pdf
VOLTAGE RATING - DC	60V
VOLTAGE RATING - AC	42V
TYPE	Capacitive, Illuminated
TERMINATION STYLE	Wire Leads
SWITCH FUNCTION	Off-On
SERIES	CPS
PANEL CUTOUT DIMENSIONS	Circular - 19.10mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-40°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP67 - Dust Tight, Waterproof
ILLUMINATION VOLTAGE (NOMINAL)	5 ~ 28 VDC
ILLUMINATION TYPE, COLOR	LED, Cyan/Magenta
FEATURES	Finger Guide, Power Symbol
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
CURRENT RATING	100mA (AC/DC)
COLOR - ACTUATOR/CAP	Silver
CIRCUIT	SPST
ACTUATOR TYPE	Round, Button, Flush

Related Tags

Schurter CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S	CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S Distributor	CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S Supplier
CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S Price	CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S Pictures	CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S Image
CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S PDF Datasheet	CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S Download Datasheet	CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S Datasheet
CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S Stock	Buy CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S	Buy Schurter CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S
Schurter CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S	Schurter Supplier	Schurter Distributor
Schurter CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S	Schurter Inc. CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1077-S	

Related Products

<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1076-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: 4063 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS19-LA00A10-SNCSNCWF-RI0CRVAR-W1003-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: 5761 pcs</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS19-LA00A10-SNCSNCWF-RI0CRVAR-W1002-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: 3455 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1073-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: 4790 pcs</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1075-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: 6291 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS19-LA00A10-SNCSNCWF-RI0CRVAR-W1005-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: 3720 pcs</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1072-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: 6981 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS19-LA00A10-SNCSNCWF-RI0CRVAR-W1001-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: 3081 pcs</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1071-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: 3375 pcs</div> <div>RFQ</div>	<div></div> <div>CPS19-LA00A10-SNCSNCWF-RI0CRVAR-W0000-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: 2858 pcs</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS19-LA00A10-SNCSNCWF-RI0CMVAR-W1074-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: 4210 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>CPS19-LA00A10-SNCSNCWF-RI0CRVAR-W1004-S</div> <div>Manufacturers: Schurter</div> <div>Description: SWITCH PUSHBUTTON SPST 100MA 42V</div> <div>In stock: 3140 pcs</div> <div>RFQ</div>