



**SCHURTER**
ELECTRONIC COMPONENTS

Schurter


**SCHURTE**
ELECTRONIC COMPONE

0041.8847.1137

Part Number:	0041.8847.1137
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSH DPST-NO 200MA 60V
Datasheets:	 0041.8847.1137.pdf
RoHs Status	 Lead free / RoHS Compliant
Stock Condition	11474 pcs stock
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION













Specifications of 0041.8847.1137

PART NUMBER	0041.8847.1137
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSH DPST-NO 200MA 60V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	11474 pcs
DATA SHEET	 0041.8847.1137.pdf
VOLTAGE RATING - DC	50V
VOLTAGE RATING - AC	60V
TYPE	Standard, Illuminated
TERMINATION STYLE	Solder Lug
SWITCH FUNCTION	Off-Mom
SERIES	LDT
PANEL CUTOUT DIMENSIONS	Circular - 8.00mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-25°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	10,000 Cycles
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP40
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	10,000 Cycles
DETAILED DESCRIPTION	Pushbutton Switch DPST-NO Standard, Illuminated Panel Mount, Front
CURRENT RATING	200mA (AC/DC)
COLOR - ACTUATOR/CAP	-
CIRCUIT	DPST-NO
ACTUATOR TYPE	Round, Button

Related Tags

Schurter 0041.8847.1137	0041.8847.1137 Distributor	0041.8847.1137 Supplier
0041.8847.1137 Price	0041.8847.1137 Pictures	0041.8847.1137 Image
0041.8847.1137 PDF Datasheet	0041.8847.1137 Download Datasheet	0041.8847.1137 Datasheet
0041.8847.1137 Stock	Buy 0041.8847.1137	Buy Schurter 0041.8847.1137
Schurter 0041.8847.1137	Schurter Supplier	Schurter Distributor
Schurter 0041.8847.1137	Schurter Inc. 0041.8847.1137	

Related Products

<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.8851.1107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16229 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.8847.5127 Manufacturers: Schurter Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 5944 pcs</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.8843.7107 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 23606 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.8845.3107 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 19126 pcs</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.8850.5127 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 13742 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.8845.4107 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 17303 pcs</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.8855.1107 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16786 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.8856.1137 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 13670 pcs</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.8846.3117 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 5352 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.8845.7107 Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 20416 pcs</div> <div>RFQ</div>
<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.8846.5127 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 15845 pcs</div> <div>RFQ</div>	<div>SCHURTER ELECTRONIC COMPONENTS</div> <div>0041.8851.3107 Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 4471 pcs</div> <div>RFQ</div>