

S.SCHURTER

Schurter

0041.9146.5327

Part Number:

Manufacturer/Brand: Product description

RoHs Status Stock Condition

Datasheets:

Ship From Shipment Way 0041.9146.5327

Schurter

SWITCH PUSH SPST-NO 200MA 60V

0041.9146.5327.pdf

Lead free / RoHS Compliant

15485 pcs stock Hong Kong

DHL/Fedex/TNT/UPS/EMS

9.SCHURTE ELECTRONIC COMPONE

Image may be representation. See specifications for product details.

Specifications of 0041.9146.5327

REQUEST FOR QUOTATION

	Specifications of 0041.9140.3327
PART NUMBER	0041.9146.5327
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSH SPST-NO 200MA 60V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	15485 pcs
DATA SHEET	0041.9146.5327.pdf
VOLTAGE RATING - DC	50V
VOLTAGE RATING - AC	60V
ТҮРЕ	Standard, Illuminated
TERMINATION STYLE	PC Pin
SWITCH FUNCTION	Off-Mom
SERIES	LDT
PANEL CUTOUT DIMENSIONS	Circular - 8.00mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-25°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
MECHANICAL LIFE	10,000 Cycles
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP40
ILLUMINATION VOLTAGE (NOMINAL)	2 VDC
ILLUMINATION TYPE, COLOR	LED, Green
FEATURES	-
ELECTRICAL LIFE	10,000 Cycles
DETAILED DESCRIPTION	Pushbutton Switch SPST-NO Standard, Illuminated Panel Mount, Front
CURRENT RATING	200mA (AC/DC)
COLOR - ACTUATOR/CAP	Green
CIRCUIT	SPST-NO

Related Tags

Square, Button

Schurter 0041.9146.5327	0041.9146.5327 Distributor	0041.9146.5327 Supplier
0041.9146.5327 Price	0041.9146.5327 Pictures	0041.9146.5327 Image
0041.9146.5327 PDF Datasheet	0041.9146.5327 Download Datasheet	0041.9146.5327 Datasheet
0041.9146.5327 Stock	Buy 0041.9146.5327	Buy Schurter 0041.9146.5327
Schurter 0041.9146.5327	Schurter Supplier	Schurter Distributor
Schurter 0041.9146.5327	Schurter Inc. 0041.9146.5327	

Related Products

0041.9146.5127

Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 9919 pcs

RFQ

9.SCHURTER

Manufacturers: Schurter

0041.9153.3107

Description: SWITCH PUSHBUTTON SPST-NO In stock: 22476 pcs

RFQ

0041.9151.7107 Manufacturers: Schurter

ACTUATOR TYPE

Description: SWITCH PUSH SPST-NO 200MA 60V

In stock: 26458 pcs

RFQ

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V

0041.9146.3117

In stock: 9762 pcs

RFQ

S.SCHURTER

9.SCHURTER

0041.9147.3317 Manufacturers: Schurter

Description: SWITCH PUSH DPST-NO 200MA 60V

In stock: 8060 pcs

RFQ

9.SCHURTER

Manufacturers: Schurter

0041.9146.1337

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 13069 pcs

RFQ

0041.9151.3107 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V

In stock: 26487 pcs

RFQ

S.SCHURTER

0041.9151.5307 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 25659 pcs

RFQ

0041.9146.3317

Manufacturers: Schurter 9.SCHURTER

Description: SWITCH PUSHBUTTON SPST-NO In stock: 13245 pcs

0041.9150.5127

RFQ

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V

In stock: 16456 pcs **RFQ**

Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V

0041.9141.7107

In stock: 26369 pcs

RFQ

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO

0041.9143.3307

In stock: 23019 pcs

RFQ



9.SCHURTER













