

S.SCHURTER

**Schurter** 

#### 0041.9157.1137

Part Number:

Manufacturer/Brand: Product description

Datasheets: RoHs Status

Stock Condition

Ship From Shipment Way 0041.9157.1137

Schurter

SWITCH PUSH DPST-NO 200MA 60V

0041.9157.1137.pdf

Lead free / RoHS Compliant 12803 pcs stock

Hong Kong DHL/Fedex/TNT/UPS/EMS

**REQUEST FOR QUOTATION** 

Image may be representation. See specifications for product details.

**9.SCHURTE** 

ELECTRONIC COMPONE

	Specifications of 0041.9157.1137
	Specifications of 60 11.5137.1137
PART NUMBER	0041.9157.1137
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSH DPST-NO 200MA 60V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	12803 pcs
DATA SHEET	0041.9157.1137.pdf
VOLTAGE RATING - DC	50V
VOLTAGE RATING - AC	60V
TYPE	Standard, Illuminated
TERMINATION STYLE	PC Pin
SWITCH FUNCTION	Off-On
SERIES	LDS
PANEL CUTOUT DIMENSIONS	Circular - 8.00mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-25°C ~ 60°C
MOUNTING TYPE	Panel Mount, Front
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	10,000 Cycles
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP40
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	10,000 Cycles
DETAILED DESCRIPTION	Pushbutton Switch DPST-NO Standard, Illuminated Panel Mount, Front
CURRENT RATING	200mA (AC/DC)
COLOR - ACTUATOR/CAP	-
CIRCUIT	DPST-NO
ACTUATOR TYPE	Round, Button

# **Related Tags**

Schurter 0041.9157.1137	0041.9157.1137 Distributor	0041.9157.1137 Supplier
0041.9157.1137 Price	0041.9157.1137 Pictures	0041.9157.1137 Image
0041.9157.1137 PDF Datasheet	0041.9157.1137 Download Datasheet	0041.9157.1137 Datasheet
0041.9157.1137 Stock	Buy 0041.9157.1137	Buy Schurter 0041.9157.1137
Schurter 0041.9157.1137	Schurter Supplier	Schurter Distributor
Schurter 0041.9157.1137	Schurter Inc. 0041.9157.1137	

## **Related Products**



### 0041.9156.5127

Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V

In stock: 8605 pcs

**RFQ** 

0041.9158.3117

SCHURTER

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO

0041.9160.5127

In stock: 11133 pcs

**RFQ** 

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO

In stock: 14414 pcs

**RFQ** 

0041.9151.3107

0041.9157.5327 Manufacturers: Schurter

Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 10073 pcs

**RFQ** 

S.SCHURTER

Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 26487 pcs

**RFQ** 

0041.9151.7107

SCHURTER

0041.9150.5127 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 13245 pcs

**RFQ** 

Manufacturers: Schurter 9.SCHURTER

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 26458 pcs

**RFQ** 

9.SCHURTER

0041.9153.3107 Manufacturers: Schurter

In stock: 22476 pcs **RFQ** 

Description: SWITCH PUSHBUTTON SPST-NO

Manufacturers: Schurter 9.SCHURTER Description: SWITCH PUSHBUTTON SPST-NO

004110101

In stock: 11686 pcs

0041.9160.3317

**RFQ** 

9.SCHURTER

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V

0041.9151.5307

In stock: 25659 pcs **RFQ** 

Altech Corp.

Manufacturers: Altech Corporation Description: FUSENH00DCM160A80VDC STRIKER IND

In stock: 1213 pcs

**RFQ** 

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO

0041.9160.1337

In stock: 13542 pcs

**RFQ** 















