





Schurter




Image may be representation. See specifications for product details.

0041.9101.72000

Part Number:	0041.9101.72000
Manufacturer/Brand:	Schurter
Product description	SWITCH PUSHBUTTON SPST-NO
Datasheets:	 0041.9101.72000.pdf
RoHs Status	 Lead free / RoHS Compliant
Stock Condition	20670 pcs stock
Ship From	Hong Kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

REQUEST FOR QUOTATION













Specifications of 0041.9101.72000

PART NUMBER	0041.9101.72000
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSHBUTTON SPST-NO
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	20670 pcs
DATA SHEET	 0041.9101.72000.pdf
TYPE	-
TERMINATION STYLE	-
SWITCH FUNCTION	-
SERIES	-
PANEL CUTOUT DIMENSIONS	-
PACKAGING	-
OPERATING TEMPERATURE	-
MOUNTING TYPE	-
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	-
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	-
DETAILED DESCRIPTION	Pushbutton Switch
CURRENT RATING	-
COLOR - ACTUATOR/CAP	-
CIRCUIT	-
ACTUATOR TYPE	-

Related Tags

Schurter 0041.9101.72000	0041.9101.72000 Distributor	0041.9101.72000 Supplier
0041.9101.72000 Price	0041.9101.72000 Pictures	0041.9101.72000 Image
0041.9101.72000 PDF Datasheet	0041.9101.72000 Download Datasheet	0041.9101.72000 Datasheet
0041.9101.72000 Stock	Buy 0041.9101.72000	Buy Schurter 0041.9101.72000
Schurter 0041.9101.72000	Schurter Supplier	Schurter Distributor
Schurter 0041.9101.72000	Schurter Inc. 0041.9101.72000	

Related Products

<div></div> <div><b>0041.9105.72000</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 17892 pcs</div> <div>RFQ</div>	<div></div> <div><b>0041.8851.3107</b> Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 4471 pcs</div> <div>RFQ</div>
<div></div> <div><b>0041.8851.1107</b> Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 16229 pcs</div> <div>RFQ</div>	<div></div> <div><b>0041.8856.1137</b> Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 13670 pcs</div> <div>RFQ</div>
<div></div> <div><b>0041.9102.72000</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON DPST-NO In stock: 17566 pcs</div> <div>RFQ</div>	<div></div> <div><b>0041.9105.71000</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16377 pcs</div> <div>RFQ</div>
<div></div> <div><b>0041.9101.81000</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 24353 pcs</div> <div>RFQ</div>	<div></div> <div><b>0041.8860.1137</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 6270 pcs</div> <div>RFQ</div>
<div></div> <div><b>0041.9141.1307</b> Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 27287 pcs</div> <div>RFQ</div>	<div></div> <div><b>0041.8855.1107</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16786 pcs</div> <div>RFQ</div>
<div></div> <div><b>0041.8850.5127</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 13742 pcs</div> <div>RFQ</div>	<div></div> <div><b>0041.9105.52000</b> Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO In stock: 16185 pcs</div> <div>RFQ</div>