

S.SCHURTER

**Schurter** 

0041.8851.1107

Part Number:

Manufacturer/Brand:

Product description

RoHs Status Stock Condition

Datasheets:

Ship From Shipment Way 0041.8851.1107

Schurter

SWITCH PUSH SPST-NO 200MA 60V

0041.8851.1107.pdf

Lead free / RoHS Compliant 16229 pcs stock

Hong Kong DHL/Fedex/TNT/UPS/EMS

**REQUEST FOR QUOTATION** 

Image may be representation. See specifications for product details.

**9.SCHURTE** 

ELECTRONIC COMPONE

	Specifications of 0041.8851.1107
PART NUMBER	0041.8851.1107
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSH SPST-NO 200MA 60V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	16229 pcs
DATA SHEET	0041.8851.1107.pdf
VOLTAGE RATING - DC	50V
VOLTAGE RATING - AC	60V
TYPE	Standard
TERMINATION STYLE	Solder Lug
SWITCH FUNCTION	Off-On
SERIES	LDS
PANEL CUTOUT DIMENSIONS	Circular - 8.00mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-25°C ~ 85°C
MOUNTING TYPE	Panel Mount, Front
MOISTURE SENSITIVITY LEVEL (MSL)	1 (Unlimited)
MECHANICAL LIFE	10,000 Cycles
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP40
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	10,000 Cycles
DETAILED DESCRIPTION	Pushbutton Switch SPST-NO Standard Panel Mount, Front
CURRENT RATING	200mA (AC/DC)
COLOR - ACTUATOR/CAP	-
CIRCUIT	SPST-NO
ACTUATOR TYPE	Round, Button

## **Related Tags**

Schurter 0041.8851.1107	0041.8851.1107 Distributor	0041.8851.1107 Supplier
0041.8851.1107 Price	0041.8851.1107 Pictures	0041.8851.1107 Image
0041.8851.1107 PDF Datasheet	0041.8851.1107 Download Datasheet	0041.8851.1107 Datasheet
0041.8851.1107 Stock	Buy 0041.8851.1107	Buy Schurter 0041.8851.1107
Schurter 0041.8851.1107	Schurter Supplier	Schurter Distributor
Schurter 0041.8851.1107	Schurter Inc. 0041.8851.1107	

## **Related Products**

0041.8847.	113/
Manufacturers:	Schurt

Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 11474 pcs

**RFQ** 

SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO

0041.8855.1107

In stock: 16786 pcs

**RFQ** 

0041.9101.72000 9.SCHURTER

9.SCHURTER

S.SCHURTER

9.SCHURTER

9.SCHURTER

9.SCHURTER

Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 20670 pcs

**RFQ** 

9.SCHURTER

0041.8845.7107 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 20416 pcs

**RFQ** 

0041.8856.1137

Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V

In stock: 13670 pcs

**RFQ** 

SCHURTER

0041.8846.5127 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 15845 pcs

**RFQ** 

0041.9101.81000 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 24353 pcs

**RFQ** 

**9.SCHURTER** 

0041.8846.3117 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 5352 pcs

**RFQ** 

Manufacturers: Schurter Description: SWITCH PUSH SPST-NO 200MA 60V

In stock: 4471 pcs

0041.8851.3107

**RFQ** 

9.SCHURTER

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO

0041.8850.5127

In stock: 13742 pcs **RFQ** 

0041.8860.1137 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 6270 pcs

**RFQ** 

0041.8847.5127 Manufacturers: Schurter

Description: SWITCH PUSH DPST-NO 200MA 60V

In stock: 5944 pcs **RFQ** 















