S.SCHURTER



**9.SCHURTE** ELECTRONIC COMPONE

0041.8851.3107 **Schurter** 

Part Number:

Manufacturer/Brand: Product description

Datasheets: RoHs Status

Stock Condition Ship From

Shipment Way

0041.8851.3107

Schurter

SWITCH PUSH SPST-NO 200MA 60V

0041.8851.3107.pdf

Lead free / RoHS Compliant 4471 pcs stock

Hong Kong

DHL/Fedex/TNT/UPS/EMS

**REQUEST FOR QUOTATION** 

Image may be representation. See specifications for product details.

	Specifications of 0041.8851.3107
	Specifications of 0041.8651.5107
PART NUMBER	0041.8851.3107
MANUFACTURER	Schurter
DESCRIPTION	SWITCH PUSH SPST-NO 200MA 60V
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
QUANTITY AVAILABLE	4471 pcs
DATA SHEET	0041.8851.3107.pdf
VOLTAGE RATING - DC	50V
VOLTAGE RATING - AC	60V
TYPE	Standard
TERMINATION STYLE	Solder Lug
SWITCH FUNCTION	Off-On
SERIES	LDS
PANEL CUTOUT DIMENSIONS	Circular - 8.00mm Dia
PACKAGING	Bulk
OPERATING TEMPERATURE	-25°C ~ 85°C
MOUNTING TYPE	Panel Mount, Front
MECHANICAL LIFE	10,000 Cycles
LEAD FREE STATUS / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP40
ILLUMINATION VOLTAGE (NOMINAL)	-
ILLUMINATION TYPE, COLOR	-
FEATURES	-
ELECTRICAL LIFE	10,000 Cycles
DETAILED DESCRIPTION	Pushbutton Switch SPST-NO Standard Panel Mount, Front
CURRENT RATING	200mA (AC/DC)
COLOR - ACTUATOR/CAP	Red
CIRCUIT	SPST-NO
ACTUATOR TYPE	Round, Button

## **Related Tags**

Schurter 0041.8851.3107	0041.8851.3107 Distributor	0041.8851.3107 Supplier
0041.8851.3107 Price	0041.8851.3107 Pictures	0041.8851.3107 Image
0041.8851.3107 PDF Datasheet	0041.8851.3107 Download Datasheet	0041.8851.3107 Datasheet
0041.8851.3107 Stock	Buy 0041.8851.3107	Buy Schurter 0041.8851.3107
Schurter 0041.8851.3107	Schurter Supplier	Schurter Distributor
Schurter 0041.8851.3107	Schurter Inc. 0041.8851.3107	

## **Related Products**

0041.8855.1107

Manufacturers: Schurter 9.SCHURTER

Description: SWITCH PUSHBUTTON SPST-NO In stock: 16786 pcs

**RFQ** 

9.SCHURTER

Manufacturers: Schurter

0041.8847.5127

Description: SWITCH PUSH DPST-NO 200MA 60V In stock: 5944 pcs

**RFQ** 

0041.8847.1137

0041.8851.1107

Manufacturers: Schurter 9.SCHURTER Description: SWITCH PUSH SPST-NO 200MA 60V

9.SCHURTER

S.SCHURTER

9.SCHURTER

S.SCHURTER

In stock: 16229 pcs

**RFQ** 

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSH DPST-NO 200MA 60V

In stock: 11474 pcs

**RFQ** 

0041.9101.81000 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO

In stock: 24353 pcs

**RFQ** 

9.SCHURTER

Manufacturers: Schurter

0041.8850.5127

Description: SWITCH PUSHBUTTON SPST-NO In stock: 13742 pcs

**RFQ** 

0041.9102.72000 Manufacturers: Schurter

Description: SWITCH PUSHBUTTON DPST-NO

In stock: 17566 pcs

**RFQ** 

S.SCHURTER

0041.8856.1137 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 13670 pcs

**RFQ** 

0041.8846.3117 Manufacturers: Schurter

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 5352 pcs

**RFQ** 

0041.8846.5127

9.SCHURTER

9.SCHURTER

Manufacturers: Schurter Description: SWITCH PUSHBUTTON SPST-NO

0041.8860.1137

In stock: 6270 pcs

**RFQ** 

0041.9101.72000

Manufacturers: Schurter

Description: SWITCH PUSHBUTTON SPST-NO In stock: 20670 pcs

**RFQ** 

Description: SWITCH PUSH SPST-NO 200MA 60V In stock: 15845 pcs

Manufacturers: Schurter

**RFQ** 











**Copyright © 2020 Reliable Distributor of Electronic Components** E-mail: Info@infinity-electronic.com Address: 17F, Gaylord Commercial Building, 114-118 Lockhart Road, Wan Chai, Hong Kong