QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 826B-A/B PUSH BUTTON ON/OFF CONTROLLER

LTC2950-2/LTC2951-2

DESCRIPTION

Demonstration Circuits 826B-A and 826B-B feature the LTC2950-2 and the LTC2951-2 respectively, which are low power, wide input voltage range, Push Button On/Off Controllers. A push button switch shorts the /PB pin to ground which in turn sets the /EN pin low (see Note 1). Shorting /PB to ground a second time subsequently resets the /EN pin high. The /EN pin is used to connect to a DC/DC converter shutdown to control the turn on and off of the circuit, simulated with a green LED on the DC826B-A/DC826B-B.

JP1 and JP2 on the DC826B-A provide the selection of timing options for the /PB on and off times. For the DC826B-B, JP1 selects /KILL times while JP2 selects off times. JP3 ties and unties /KILL to /INT for immediate or delayed turn off. The /INT status is shown with a red LED. DC826B-A/DC826B-B accepts an input voltage range of 2.7V to 26.4V or a 9V battery for portable demonstration and evaluation.

Design files for this circuit board are available. Call the LTC factory.

Note 1: The inversion of /EN of the LTC2950-2/LTC2951-2 is found in the LTC2950-1/LTC2951-1. Table 1 provides an IC selection guide.

QUICK START PROCEDURE

Demonstration circuit 826B-A/826B-B is easy to set up to evaluate the performance of the LTC2950-2/LTC2951-2:

- 1. Place jumpers in the following positions:
 - JP1 0.033uF
 - JP2 0.033uF
 - JP3 UNTIE

- **2.** Connect the input power supply of 2.7V to 26.4V across VIN and GND or a 9V battery to the battery connector.
- **3.** Push and hold the push button once to turn on the green LED.
- 4. Push and hold the push button again to turn off the green LED.

Table 1. LTC2950/2951 Selection Guide (typical timing values, Cap. Adjust = 212ms on DC826B-A/ DC826B-B)

PART	ENABLE	ONT	OFFT	KILLT	DEMO BOARD
LTC2950-1	EN	32ms + Cap. Adjust*	32ms + Cap. Adjust*	1000ms	N/A
LTC2590-2	/EN	32ms + Cap. Adjust*	32ms + Cap. Adjust*	1000ms	DC826B-A
LTC2951-1	EN	128ms	32ms + Cap. Adjust*	128ms + Cap. Adjust*	N/A
LTC2951-2	/EN	128ms	32ms + Cap. Adjust*	128ms + Cap. Adjust*	DC826B-B

*The additional Cap. Adjust time is selected by an external capacitor. The DC826B-A and DC826B-B adjust times have been pre-selected with a 0.033uF capacitor to provide an additional 212ms. The additional time is calculated with the following equations as shown in the LTC2950/LTC2951 data sheets:

 $C_{ONT} = 1.56E-4 \ [\mu F/ms] \bullet (t_{ONT} - 1ms)$

$$C_{OFFT} = 1.56E-4 \ [\mu F/ms] \bullet (t_{OFFT} - 1ms)$$

 $C_{\text{KILLT}} = 1.56\text{e-4} \; [\mu\text{F/ms}] \bullet (t_{\text{/KILL, OFF DELAY, ADDITIONAL}} - 1\text{ms})$



OPERATING PRINCIPLES

The duration that /PB must be shorted to ground in order to turn on/off the DC/DC converter is independently programmed (LTC2950-2) by two external capacitors C1 and C2 and selected on the DC826B-A with jumper JP1 and JP2. The status of the /EN pin, and simulation of the turn on/off of a DC/DC converter, is displayed with green LED D2 on the board.

Figure 1 shows how the /EN is connected to the /SHDN pin of a DC/DC converter and how /INT and /KILL interfaces with a μ P or μ C. An internal 500ms timer blanks (ignores) the /KILL signal during system power up. This allows sufficient time for the DC/DC converter and a µP to perform power up tasks. During turn off, a power down timer provides a delay (LTC2950-2: 1000mS, LTC2951-2: adjustable) from interrupting the μP (/INT=low) to turning off the DC/DC converter (/EN=high). This delay gives the μ P time to perform power down and housekeeping tasks. On the DC826B-B, JP1 selects the power down timer, while JP2 is used to adjust the turn off /PB duration. The red LED D1 shows the state of the /INT pin. A μ P can turn off the converter with no delay by asserting /KILL low. By tying /KILL to /INT through JP3, /KILL is forced low during the /INT blanking time and thus force a turn off.

The RC (R_{RPP} and C_{RPP}) at VIN on the DC826 provides reverse polarity protection to the LTC2950-2/LTC2951-2. If power is connected in an application such that the polarities are ensured to be in the correct configuration, this RC may be removed from the circuit.

An additional RC (R_F and C_F), located at the /PB pin, acts as a filter and used in an application where the switch is located far from the LTC2950-2/LTC2951-2. In such a case, the RC would be placed next to the switch rather than the part. If the switch is located near the LTC2950-2/LTC2951-2, then the RC may be removed from the circuit.

An LDO (U2) is used on the DC826 to provide a pullup voltage of 2.6V which is well below the absolute maximum on the /INT, /EN, and /KILL pins for the full range of input voltage of 2.7V to 26.4V. In an application, pull these pins up to a voltage no higher than their rated absolute maximum shown in the data sheet. Optional zener diodes (D3-D5) can be used if the pull-up voltage exceeds the rated absolute maximum. (If the interface pins on the DC826B-A /DC826B-B will be pulled up to an external supply, LEDs D1 and D2 should be removed.)





Figure 1. DC826B-A/DC826B-B Example Setup

QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 826B-A/B PUSH BUTTON ON/OFF CONTROLLER



TECHNOLOGY